



STREET KIT PAD BED IN PROCEDURE

After reaching medium speed, engage the brake pedal to slow the car without coming to a complete stop. Release the pedal quickly and do not drag the brakes. Repeat 4-5 times.

At higher speeds, engage the pedal to slow the car without coming to a complete stop. Release the pedal quickly and do not drag the brakes.

At or near race speed, engage the brake pedal to slow the car without coming to a complete stop. Release the pedal quickly and do not drag the brakes.

Repeat three times. Allow a few seconds between brake engagements while car is in motion.

Do not hold the brake pedal. Park car for approximately 20 minutes or until rotors are completely cool to the touch.

If during the above steps the brake pedal becomes soft or brake fade is noticed, park the car for approximately 20 minutes. Do not hold brake pedal.

Important reminders:

- Do not attempt to use badly worn or damaged rotors with new brake pads.
- Do not drag brakes while car is moving during brake in procedure.
- Do not engage pedal while the car is stopped at any time following the break in procedure.
- Upon completing the procedure, allow the brake system to completely cool before racing.
- Applying the pedal a few times before the start of the race will allow the brakes to heat up before attempting to reach race speeds.
- Clean a used rotor surface with fine sand paper or steel wool, rinse with water or acetone, dry and install before bedding new pads.

